

# ECO-INDICATOR

Confirm system operation and adequate pressure with this handy visual device.

## KEY BENEFITS

- Visible bright yellow or reclaimed purple riser stem and cap indicate when system is in operation
- Stem pops up when pressure exceeds the threshold and assists in confirming low pressures if not raised
- Connects via bottom or side inlet ports for easy installation; side inlet port is available on 12" version
- Can be used as a flush valve on drip systems by removing the nozzle

## OPERATING SPECIFICATIONS

- ECO-ID:
  - Operating pressure: up to 70 PSI
  - Indication of system operation: above 12 PSI
  - Warranty period: 2 years
- ECO-ID-12, ECO-ID-12-R:
  - Operating pressure: up to 100 PSI
  - Indication of system operation: above 15 PSI
  - Warranty period: 5 years

## USER-INSTALLED OPTIONS FOR 12" ECO-INDICATOR

- Drain check valve (up to 10' of elevation; P/N 437400SP)
- SJ Swing Joint: SJ-512 (½" threaded x 12" length)

ECO-INDICATOR	
Model	Description
ECO-ID	6" Eco-Indicator
ECO-ID-12	12" Eco-Indicator
ECO-ID-12-R	12" Eco-Indicator, Reclaimed

Eco-Indicator Installed



### ECO-ID

Retracted height: 9½"  
Pop-up height: 6"  
Exposed diameter: 1¼"  
Inlet size: ½"



### [A] ECO-ID-12


### [B] ECO-ID-12-R

Retracted height: 16½"  
Pop-up height: 12"  
Exposed diameter: 2¼"  
Inlet size: ½"

Compatible with:



**Eco-Mat®  
System**  
Page 168



**Eco-Wrap®  
System**  
Page 169



**HDL Dripline**  
Page 162