

**PROGRAMMABLE
SENSOR OVERRIDE**Hold **■**, turn to Start Times**CYCLE AND SOAK**Hold **+**, turn to Run Times
Press **PRG** to set Soak**DELAY BETWEEN
STATIONS**Hold **■**, turn to Run Times**HIDE PROGRAMS**Hold **■**, turn to Water Days**SOLAR SYNC DELAY**Hold **+**, turn to Solar Sync**CLIK DELAY**Hold **+**, turn to System Off

Feature

Where Found

TOTAL RUN TIME

Turn to Run Times
Press ◀ from Station 1 to view

TEST PROGRAM

Hold **PRG** for 3 seconds

EASY RETRIEVE™

Press **+** and **PRG** to Save
Press **-** and **PRG** to Restore

TOTAL RESET

Press **PRG** and **RESET** button

QUICK CHECK™

Press **+**, **-**, **◀**, **▶** together
Press **+** to begin check

RUN PROGRAM

Hold **▶**, press **PRG** to select